



Put the 2 larger holes over the nasal pillows with the smaller hole toward you.

Take your thumb and forefinger and stretch both small holes as needed.



Hold the fabric towards the pillows and lay the small stretched holes over the end of the pillows.

Hold the pillows to your nose and pull head gear over your head. Adjust the liner for a comfortable fit with your thumb and forefinger.

